Please amend the specification as follows:

Please replace the paragraph beginning at page 3, lines 20-21, with the following

amended paragraph:

Figure 3 is a sectional view along 2-2 of another alternative embodiment of the

disposable absorbent article of Figure 1.

Please replace the paragraph beginning at page 3, lines 22 - 23, with the following

amended paragraph:

Figure 4 is a schematic top view of a strike-through plate which may be used to measure

Liquid Strike-through Through of a substrate.

Please replace the paragraph beginning at page 8, lines 16 - 19, with the following

amended paragraph:

In one optional embodiment of the present invention the durable hydrophilic

acquisition layer has a wash-off surface tension of greater than about 65 mN/m, when

tested in accordance with the Determination of surface tension Surface Tension Test in the

Test Methods section and further described herein.

Please replace the paragraph beginning at page 8, line 24-29, with the following

amended paragraph:

Figure 3 is a sectional view along-2-2 showing a section of one alternative

embodiment of the diaper 20 of Figure 1. In Figure 3 the storage layer 80 and the

acquisition layer 70 are surrounded or enveloped by the core wrap 42. The core wrap 42

comprises a substrate, such as a nonwoven, material, film and combinations thereof. In

one optional embodiments of the present invention the core wrap may be coated with a

hydrophilicity boosting composition, which are exemplified in more detail herein.

Please replace the paragraph beginning at page 8, line 30 – page 9, line 6, with the

following amended paragraph:

Acquisition Layer Substrate - The durable hydrophilic core wrap acquisition layer of the

present invention comprises an acquisition layer substrate (substrate) which has been

Page 2 of 23

Appl. No. 10/758,138 Atty. Docket No. 9162Q Amdt. dated May 22, 2006 Reply to Office Action of Jan. 20, 2006 Customer No. 27752

coated with a hydrophilicity boosting composition. The substrate of interest herein may comprise any known type of substrate, including but not limited to fabrics, garments, textiles, and films. In certain embodiments, the substrate may comprise one or more fibers. A fiber is defined as a fine hairlike structure, of animal, vegetable, mineral, or synthetic origin. Commercially available fibers have diameters ranging from less than about 0.001 mm (about 0.00004 in) to more than about 0.2 mm (about 0.008 in) and they come in several different forms: short fibers (known as staple, or chopped), continuous single fibers (filaments or monofilaments), untwisted bundles of continuous filaments (tow), and twisted bundles of continuous filaments (yarn).

Please replace the paragraph beginning at page 13, lines 3 - 12, with the following amended paragraph:

Typically the amount of hydrophilicity boosting compositions present on a substrate will vary depending upon many factors, including but not limited to, the substrate used, the nanoparticles used, the desired hydrophilicity of the durable hydrophilic acquisition layer, the consumer product in which the absorbent core is used, etc. Preferably, the amount of hydrophilicity boosting compositions on the substrate will be present invention—will be between about 0.01 grams of hydrophilicity boosting composition per square meter of substrate (or gsm substrate) and about 30 gsm substrate, more preferably between about 0.01 gsm substrate and about 20 gsm substrate, even more preferably between about 0.1 gsm substrate and about 10 gsm substrate. In one preferred embodiment of the present invention the nanoparticles are applied to the substrate as a dispersion in a carrier.

Please replace the paragraph beginning at page 14, lines 7 - 14, with the following amended paragraph:

Either organic or inorganic nanoparticles may be used in the hydrophilicity boosting composition of the present invention. Suitable organic nanoparticle include, but are not limited to, nanolatexes. A "nanolatex", as used herein, is a latex with particle sizes less than or equal to about 750 nm. A "latex" is a colloidal dispersion of water-insoluble polymer particles that are usually spherical in shape. Nanolatexes may be formed by emulsion polymerization. "Emulsion polymerization" is a process in which monomers of the latex are dispersed in water using a surfactant to form a stable emulsion followed by

Appl. No. 10/758,138 Atty. Docket No. 9162Q Amdt. dated May 22, 2006

Reply to Office Action of Jan. 20, 2006

Customer No. 27752

polymerization. Particles are produced with can range in size from about 2 to about 600 nm.

Please replace the paragraph beginning on page 15, lines 1-9, with the following amended paragraph:

In one preferred embodiment of the present invention the nanoparticles comprise a synthetic hectorite which can be a lithium magnesium silicate. One such suitable lithium magnesium silicate is LAPONITE[[TM]]®, which has the formula:

$$[Mg_w Li_x Si_8 O_{20} OH_{4-y} F_v]^{z-}$$

wherein w = 3 to 6, x = 0 to 3, y = 0 to 4, z = 12 - 2w - x, and the overall negative lattice charge is balanced by counter-ions; and wherein the counter-ions are selected from the group consisting of selected Na⁺, K⁺, NH₄⁺, Cs⁺, Li⁺, Mg⁺⁺, Ca⁺⁺, Ba⁺⁺, N(CH₃)₄⁺ and mixtures thereof. (If the LAPONITE[[TM]]® is "modified" with a cationic organic compound, then the "counter-ion" could be viewed as being any cationic organic group (R).)

Please replace the paragraph beginning at page 15, lines 29 - 30, with the following amended paragraph:

Optional ingredients - The hydrophilicity boosting compositions of the present invention may also include optional ingredients such as[[,]] a carrier, surfactant and adjunct ingredients.

Please replace the paragraph beginning at page 20, lines 6 - 17, with the following amended paragraph:

Apparatus-Lister Strike-through Through Equipment- (i) A Funnel fitted with magnetic valve: Rate of discharge of 25ml in 3,5 (± 0.25) seconds; (ii) A Strike-through Through plate: Constructed of 25 mm thick acrylic glass. The total weight of the plate must be 500 g. The electrodes should be of non-corrosive material. The electrodes are set in (4.0 mm x 7.0 mm) cross section grooves, cut in the base of the plate and fixed with quick setting epoxy resin. Figures 4, 5, and 6 illustrate a Strike-through Through plate 200 containing electrodes 210. Figure 4 is a top view of a Strike-through Through plate 200, where as Figure 5 is a sectional view along 5-5 of the Strike-through Through plate 200 of Figure 4. Figure 6 is a sectional perspective view along 6-6 of the Strike-through Through plate 200

Appl. No. 10/758,138 Atty. Docket No. 9162Q Amdt. dated May 22, 2006 Reply to Office Action of Jan. 20, 2006 Customer No. 27752

of Figure 4; (iii) Base plate: A square of acrylic glass 125 mm x 125 mm approximately; (iv) Ring stand to support the funnel; (v) Electronic Timer measuring to 0.01 seconds; (vi) Burette with 50 ml capacity; and (vii) Core filter paper Ahlström Grade 989 or equivalent (average Strike-through time 1.7s + - 0.3 s, dimensions: 10 x 10 cm).

Please replace the paragraph beginning at page 20, lines 18 - 33, with the following amended paragraph:

Procedure: (1) Carefully cut the required number of samples, 12.5cm x 12.5cm with touching the sample only at the edge of the sample. (2) Taking 10 plies of Core filter paper place one sample on the set of 10 plies of filter paper on the base plate. The sample should be positioned on the filter paper in such a way that the side of the nonwoven, which is intended to face the user's skin (when applied in an absorbent article) is uppermost. (3) Place the strike-through Strike-Through plate on top with the center of the plate over the center of the test piece. Center the burette and the funnel over the plate. (4) Ensuring that the electrodes are connected to the timer, switch on the timer and set the clock to zero. (5) Fill the burette with saline solution (0.9 wt% NaCl in deionized water). (6) Keep the discharge valve of the funnel closed and run 5.0 ml of liquid (= one gush) from the burette into the funnel. (7) Open the magnetic valve of the funnel to discharge 5.0 ml of liquid. The initial flow of liquid will complete the electrical circuit and start the timer. It will stop when the liquid has penetrated into the pad and fallen below the level of the electrodes in the strike-through Strike-Through plate. (8) Record the time indicated on the electronic timer. (9) Wait 60 seconds and repeat steps (4), and (6) to (9) for the second, the third gush and any subsequent gush, with each gush comprising 5 ml of liquid. (e.g., 5ml into funnel, open magnetic valve, etc.) Record the Time for the 1st, 2nd and any subsequent gush in seconds.

Please delete the paragraph beginning on page 21, lines 1-3.

Please see a replacement (or new) abstract on the attached separate sheet